



Culvert Replacement Work Zone

E = Northbound Detour
E = Southbound Detour

Sheridan Drive Detour
for
Culvert Replacement
April 2007